

POLISHING STEPS

1. First clean the ARTZ embossed panel with a cotton cloth.
2. Do sealer coating twice or more on the clear embossed panel.
3. Apply Duco Color (Golden/Silver) after soaking the coats (Powder + Lacquer + Thinner)
4. After drying, apply lacquer on Duco Color Coating twice or more as per your requirement.
5. Apply a mixture of spirit polish and black powder on the whole panel.
6. Clean the spirit polish gently with spirit and a cotton cloth.
7. Apply lacquer coating after cleaning the panel.
8. After coating is complete, use glossy, matt or semi-glossy finish as per your requirement.

पॉलिश करने की विधि

- 1 सबसे पहले ARTZ एम्बोस्ड पैनल को सूती कपड़े से साफ करें।
- 2 साफ किये हुए एम्बोस्ड पैनल पर सीलर की दो बार या उससे अधिक जरूरत के हिसाब से कोटिंग करें।
- 3 (पाउडर + लैकर + थिन्नेर) कोटिंग सूखने के बाद पूरे पैनल पर ड्यूको कलर (गोल्डन/सिल्वर) करें।
- 4 सूखने के बाद ड्यूको कलर पर जरूरत के हिसाब से दो बार या उससे अधिक लैकर से कोटिंग करें।
- 5 स्पिरिट पोलिश और काला पाउडर मिलाकर पूरे पैनल पर लगा दें।
- 6 स्पिरिट पोलिश को स्पिरिट और सूती कपड़े से हल्के हाथ से साफ करें।
- 7 साफ करने के उपरान्त पैनल पर लैकर की कोटिंग करें।
- 8 अन्त में ग्लोसी, मैट, सेमी ग्लोसी फिनिश की आप इच्छानुसार कोटिंग कर सकते हैं।

TECHNICAL SPECIFICATIONS

Core material	High Density Fibre Board (HDF)
Thickness	2.3mm
Panel Size	8ft (2440mm) x 4ft (1220mm)
Available in	Raw Unpolished
Polish Type	DUCO Finish / Dual Tone with Antique Effect / PU Finish
Fixing	Fix as Veneer
Applications	Wall/Ceiling Cladding, Shutter Cladding and Furniture Embellishments



CENTURYHDF®

Century Plyboards (India) Limited
Engineered Panel Products Division

Sales & Marketing Office: Tower B - 8th Floor, Vatika Mindscape,
Sector 27D, Faridabad, Haryana - 121003.
Ph.: 7042399909 | Email: provwud@centuryply.com

Follow us on: www.centuryhdf.com



For more information, call:

1800-200-0440